

---

## COOBER KOVE 450 QUICKSHIFTER – Calibration Guide

**⚠ Important:** Ensure the bike is securely balanced—ideally with the rider seated and the left foot on the gear shifter. Transmission **must be in neutral**.

---

### Self Learning (SL) Operation – Step-by-Step

---

#### Step 1: Ignition Key OFF

Turn the bike's ignition **completely OFF**.

---

#### Step 2: SL Coupler Disconnected (Open)

Ensure the **Self Learning Coupler is open** (disconnected).



---

**Step 3: Ignition Key ON**

Turn the ignition **ON**, but **do not start the engine**.

---

**Step 4a: Wait 10 Seconds**

Allow the system to initialize.

---

**Step 5: Connect SL Coupler (Closed)**

Now connect the **SL coupler together** (close the loop).



**Step 5a: Wait 5 Seconds Again**

Give the system another moment to register.

---

**Step 6: Perform 10–15 Up-Shifts**

- While the engine is **OFF**
  - Apply **normal riding force (like you use when drive)** to the gear lever
  - **Only up-shift**
- 

**⚠ Step 7: Do NOT Down-Shift!**

Down-shifting will invalidate the calibration.

---

**Step 8: Disconnect SL Coupler (Open Again)**

After the shifts, unplug the SL coupler once more.



**Step 9: Wait 5 Seconds**

Give the system a final moment to register disconnection.

---

**Step 10: Settings Stored**

The Quickshifter now stores the learned settings to internal memory.

---

**Step 10a: Store SL Coupler**

Securely **place the SL coupler near the battery** for future use.

---

**Step 11: Turn OFF Ignition**

Completely shut off the ignition.

---

**Step 12: Wait 5 Seconds**

Final wait before first ride.

---

**Step 13: Start the Bike and Ride!**

Quickshifter is now calibrated and ready for action. Enjoy!

---